



S82 W18717 Gemini Drive; Muskego, Wisconsin 53150
Phone: (877) 622-2694
Fax: (888) 679-3319
www.nabcoentrances.com
Technical Support: (866) 622-8325
NABCO hours of Operation: Monday to Friday 8:00 a.m.- 4:30 p.m. (Central Time)

1505 Convenience Window

OWNER’S MANUAL

WARNING

- Turn OFF all power to the Automatic Window if a Safety System is not working.
- Instruct the Owner to keep all power turned OFF until corrective action can be achieved by a NABCO trained technician. Failure to follow these practices may result in serious consequences.

Table of Contents

CHAPTER 1: SAFETY..... 2

CHAPTER 2: GENERAL SAFETY RECOMMENDATIONS 2

CHAPTER 3: SCOPE..... 2

SECTION 3.1: To the Customer2

SECTION 3.2: Objective2

CHAPTER 4: GETTING STARTED 2

SECTION 4.3: Limited Warranty2

SECTION 4.4: Service Availability3

SECTION 4.5: Information Provided by Window Supplier3

CHAPTER 5: OPERATION..... 3

CHAPTER 6: DAILY SAFETY CHECK 3

CHAPTER 1: SAFETY

Please refer to this page in the event that a warning label is displayed within this manual and further definition needs to be explained.

WARNING

Indicates a hazardous situation which has some probability of *severe injury*. It should not be considered for property damage unless personal injury risk is present.

CAUTION

Indicates a hazardous situation which may result in a *minor injury*. Caution should not be used when there is a possibility of serious injury. Caution should not be considered for property damage accidents unless a personal injury risk is present.

Notice: Indicates a statement of company policy as the message relates to the personal safety or protection of property. Notice should not be used when there is a hazardous situation or personal risk.

Attention: A situation where material could be damaged or the function impaired.

Note: Indicates important information that provides further instruction.

CHAPTER 2: GENERAL SAFETY RECOMMENDATIONS

WARNING

An improperly adjusted Window can cause injury and/or equipment damage.

WARNING

Safety devices must be installed correctly and operational.

WARNING

Do Not operate any Window Unit without fully understanding how a Window functions. If you do not fully understand, ask a qualified technician. Failure to do so may result in bodily injury, or property damage and will nullify all warranties.

Notice: This manual must be given to and retained by the purchasing facility or end user.

Notice: Inspect Window operation daily using the Daily Safety Checklist (within this manual).

CHAPTER 3: SCOPE

SECTION 3.1: To the Customer

The purpose of this manual is to familiarize the Owner with proper operation of the Window. It is essential that the Owner recognizes the importance of maintaining a Window system in compliance with industry standards for safety.

It is the responsibility of the Owner/Caretaker to inspect operation of the Window on a daily basis. Daily inspection must be done to ensure safe Window operation.

SECTION 3.2: Objective

This manual provides operation instructions and a daily safety checklist.

CHAPTER 4: GETTING STARTED

SECTION 4.3: Limited Warranty

NABCO Entrances Inc., for its Gyro-Tech product line, provides to its customer a limited warranty on products. The warranty is:

NABCO ENTRANCES INC. will exchange or repair, F.O.B. the plant, any component found defective in workmanship and/or material, subject to NABCO's inspection, for a period of one (1) year after installation or 18 months after manufacture, whichever comes first. Warranty does not include field service labor. The installing contractor/customer will be responsible for installation and field service. This is NABCO ENTRANCES Inc.'s sole warranty.

This warranty does not cover loss or damages resulting from causes beyond the manufacturer's control, misuse, neglect, accidents, windstorms, or other acts of God, or acts of terrorism. Warranty is for normal use and service. The warranty does not apply to equipment that has been repaired or altered so as to adversely affect conditions of operation. Warranty will not obligate NABCO for damages resulting from such alterations, misuse, or acts of God, or acts of terrorism.

SECTION 4.4: Service Availability



Window products are distributed through a nationwide network of authorized suppliers for sales, installation, and service. Immediately contact the Window Manufacturer or the Authorized Window Manufacturer Representative if service must be performed on any Window system.

SECTION 4.5: Information Provided by Window Supplier

The Window Supplier must provide the Owner/Caretaker:

- ▶ Instruction on how to conduct the Daily Safety Check.
- ▶ Location of Function Switches and instruction in their use.
- ▶ Circuit Breaker or Main Power disconnect location for each Window System.
- ▶ Contact number to call for service, or inquiries about the Window system, and/or to report concerns.
- ▶ Warranty information for each Window.

CHAPTER 5: OPERATION

ON	When the switch is in ON position, the window is operational.	
OFF	When the switch is in the OFF position, the window is not operational. The OFF position does not shut off the main power to the window unit.	
FULL OPEN	When the switch is in FULL OPEN position, the Window Fully opens with an activation signal.	
PARTIAL OPEN	When the switch is in PARTIAL OPEN position, the Window partially opens with an activation signal.	
LIGHT ON	When the switch is in LIGHT ON position, the overhead light will be ON.	
LIGHT OFF	When the switch is in LIGHT OFF position, the overhead light will be OFF.	
OPEN-CLOSE	When pushed, the window will open if it is in the closed position, and close if it is in the open position.	
Holding Beams	When the holding beam is blocked with a hand or object, the Convenience Window opens. Window will close after the holding Beam is no longer blocked and Time Delay setting in the Controller expires.	

CHAPTER 6: DAILY SAFETY CHECK

The best time to perform a Daily Safety Check is early in the morning before the Customer/Vehicular traffic gets busy. The purpose of a Daily Safety Check is to maintain proper Slide Window operation and/or detect any abnormal or unusual activity.

CAUTION

Any components showing signs of wear must be replaced as a preventive measure. Call a NABCO trained technician for repairs.

1. Ensure the Rocker switch is set to "ON".
2. Visually inspect the Convenience Window for proper operation.
 - a. The motion of the Convenience Window should slide freely.
3. Keep Work Counter Clean at all times.
4. Check for damaged or missing Weathering and/or Vinyl Seals.
5. Check glass window for cracks or damage.
6. Ensure the Header Cover and all other hardware is properly secured.